



Avaya 2007 IP Deskphone Call Center User Guide

Avaya Communication Server 1000

Document Status: **Standard**

Document Version: **06.01**

Part Code: **NN43118-102**

Date: **March 2013**



© 2013 Avaya Inc. All Rights Reserved.

Notice

While reasonable efforts have been made to ensure that the information in this document is complete and accurate at the time of printing, Avaya assumes no liability for any errors. Avaya reserves the right to make changes and corrections to the information in this document without the obligation to notify any person or organization of such changes.

Documentation disclaimer

"Documentation" means information published by Avaya in varying mediums which may include product information, operating instructions and performance specifications that Avaya generally makes available to users of its products. Documentation does not include marketing materials. Avaya shall not be responsible for any modifications, additions, or deletions to the original published version of documentation unless such modifications, additions, or deletions were performed by Avaya. End User agrees to indemnify and hold harmless Avaya, Avaya's agents, servants and employees against all claims,

lawsuits, demands and judgments arising out of, or in connection with, subsequent modifications, additions or deletions to this documentation, to the extent made by End User.

Link disclaimer

Avaya is not responsible for the contents or reliability of any linked websites referenced within this site or documentation provided by Avaya. Avaya is not responsible for the accuracy of any information, statement or content provided on these sites and does not necessarily endorse the products, services, or information described or offered within them. Avaya does not guarantee that these links will work all the time and has no control over the availability of the linked pages.

Warranty

Avaya provides a limited warranty on its hardware and Software ("Product(s)"). Refer to your sales agreement to establish the terms of the limited warranty. In addition, Avaya's standard warranty language, as well as information regarding support for this Product while under warranty is available to Avaya customers and other parties through the Avaya Support website:

<http://support.avaya.com>

Please note that if you acquired the Product(s) from an authorized Avaya reseller outside of the United States and Canada, the warranty is provided to you by said Avaya reseller and not by Avaya. "Software" means computer programs in object code, provided by Avaya or an Avaya Channel Partner, whether as stand-alone products or pre-installed on hardware products, and any upgrades, updates, bug fixes, or modified versions thereto.

Licenses

THE SOFTWARE LICENSE TERMS AVAILABLE ON THE AVAYA WEBSITE, [HTTP://SUPPORT.AVAYA.COM/LICENSEINFO](http://support.avaya.com/licenseinfo) ARE

APPLICABLE TO ANYONE WHO DOWNLOADS, USES AND/OR INSTALLS AVAYA SOFTWARE, PURCHASED FROM AVAYA INC., ANY AVAYA AFFILIATE, OR AN AUTHORIZED AVAYA RESELLER (AS APPLICABLE) UNDER A COMMERCIAL AGREEMENT WITH AVAYA OR AN AUTHORIZED AVAYA RESELLER. UNLESS OTHERWISE AGREED TO BY AVAYA IN WRITING, AVAYA DOES NOT EXTEND THIS LICENSE IF THE SOFTWARE WAS OBTAINED FROM ANYONE OTHER THAN AVAYA, AN AVAYA AFFILIATE OR AN AVAYA AUTHORIZED RESELLER; AVAYA RESERVES THE RIGHT TO TAKE LEGAL ACTION AGAINST YOU AND ANYONE ELSE USING OR SELLING THE SOFTWARE WITHOUT A LICENSE. BY INSTALLING, DOWNLOADING OR USING THE SOFTWARE, OR AUTHORIZING OTHERS TO DO SO, YOU, ON BEHALF OF YOURSELF AND THE ENTITY FOR WHOM YOU ARE INSTALLING, DOWNLOADING OR USING THE SOFTWARE (HEREINAFTER REFERRED TO INTERCHANGEABLY AS "YOU" AND "END USER"), AGREE TO THESE TERMS AND CONDITIONS AND CREATE A BINDING CONTRACT BETWEEN YOU AND AVAYA INC. OR THE APPLICABLE AVAYA AFFILIATE ("AVAYA").

Heritage Nortel Software

"Heritage Nortel Software" means the software that was acquired by Avaya as part of its purchase of the Nortel Enterprise Solutions Business in December 2009. The Heritage Nortel Software currently available for license from Avaya is the software contained within the list of Heritage Nortel Products located at <http://support.avaya.com/licenseinfo> under the link "Heritage Nortel Products". For Heritage Nortel Software, Avaya grants Customer a license to use Heritage Nortel Software provided hereunder solely to the extent of the authorized activation or authorized usage level, solely for the purpose specified in the Documentation, and solely as embedded in, for execution on, or (in the event the applicable Documentation permits installation on non-Avaya equipment) for communication with Avaya equipment. Charges for Heritage Nortel Software may be based on extent of activation or use authorized as specified in an order or invoice.

Copyright

Except where expressly stated otherwise, no use should be made of materials on this site, the Documentation, Software, or hardware provided by Avaya. All content on this site, the documentation and the Product provided by Avaya including the selection, arrangement and design of the content is owned either by Avaya or its licensors and is protected by copyright and other intellectual property laws including the sui generis rights relating to the protection of databases. You may not modify, copy, reproduce, republish, upload, post, transmit or distribute in any way any content, in whole or in part, including any code and software unless expressly authorized by Avaya. Unauthorized reproduction, transmission, dissemination, storage, and or use without the express

written consent of Avaya can be a criminal, as well as a civil offense under the applicable law.

Third-party components

"Third Party Components" mean certain software programs or portions thereof included in the Software that may contain software (including open source software) distributed under third party agreements ("Third Party Components"), which contain terms regarding the rights to use certain portions of the Software ("Third Party Terms"). Information regarding distributed Linux OS source code (for those Products that have distributed Linux OS source code) and identifying the copyright holders of the Third Party Components and the Third Party Terms that apply is available in the Documentation or on Avaya's website at: <http://support.avaya.com/Copyright>. You agree to the Third Party Terms for any such Third Party Components.

Note to Service Provider

The Product may use Third Party Components that have Third Party Terms that do not allow hosting and may need to be independently licensed for such purpose.

Preventing Toll Fraud

"Toll Fraud" is the unauthorized use of your telecommunications system by an unauthorized party (for example, a person who is not a corporate employee, agent, subcontractor, or is not working on your company's behalf). Be aware that there can be a risk of Toll Fraud associated with your system and that, if Toll Fraud occurs, it can result in substantial additional charges for your telecommunications services.

Avaya Toll Fraud intervention

If you suspect that you are being victimized by Toll Fraud and you need technical assistance or support, call Technical Service Center Toll Fraud Intervention Hotline at +1-800-643-2353 for the United States and Canada. For additional support telephone numbers, see the Avaya Support website: <http://support.avaya.com>. Suspected security vulnerabilities with Avaya products should be reported to Avaya by sending mail to: securityalerts@avaya.com.

Trademarks

The trademarks, logos and service marks ("Marks") displayed in this site, the Documentation and Product(s) provided by Avaya are the registered or unregistered Marks of Avaya, its affiliates, or other third parties. Users are not permitted to use such Marks without prior written consent from Avaya or such third party which may own the Mark. Nothing contained in this site, the Documentation and Product(s) should be construed as granting, by implication, estoppel, or otherwise, any license or right in and to the Marks without the express written permission of Avaya or the applicable third party.

Avaya is a registered trademark of Avaya Inc.

All non-Avaya trademarks are the property of their respective owners, and "Linux" is a registered trademark of Linus Torvalds.

Downloading documents

For the most current versions of documentation, see the Avaya Support website:

<http://support.avaya.com>

Contact Avaya Support

See the Avaya Support website: <http://support.avaya.com> for product notices and articles, or to report a problem with your Avaya product.

For a list of support telephone numbers and contact addresses, go to the Avaya Support website: <http://support.avaya.com>, scroll to the bottom of the page, and select Contact Avaya Support.

Contents

About the Avaya 2007 IP Deskphone	8
Basic features	8
IP Deskphone controls	9
IP Deskphone Display	12
Application area	13
Tools/Navigation area	15
Touch panel	17
Calibrate the touch panel	18
Using the stylus	18
Cleaning the phone Screen	18
Entering and editing text	19
Entering text using the phone dialpad	19
Editing text using the soft keys	20
Entering text using the pop-up keyboard	20
Entering text using the USB keyboard	21
Agent and Supervisor features	22
Agent Login	22
Login with Agent ID and Multiple Queue Assignments	23
Agent ID and MQA login options	24
Default Login	26
Agent Logout	27
Agent features	28
Answer ACD calls	28
Use Force Call	29
Use Activity code	30
Use Emergency	31

Use Not Ready	31
Place or answer non-ACD calls	32
Contact the supervisor	33
Using Record On Demand key	35
Using SAVE key	35
Using voice mail soft keys	36
Supervisor features	38
Use Answer Agent	38
Use Agent key	39
Use Answer Emergency	39
Use Call Agent	40
Use Interflow	40
Use Night Service	41
Observe	42
Display Queue	42
Display Agent status	44
Terms you should know	46
Regulatory and safety information	52
Other	54
DenAn regulatory notice for Japan	54
Index	56

Revision history

March 2013

Standard 06.01. This document is up-issued to support Avaya Communication Server 1000 Release 7.6.

November 2010

Standard 05.01. This document is up-issued to support Avaya rebranding changes.

August 2010

Standard 04.02. This document is up-issued to support Avaya Communication Server 1000 Release 7.0. Rebranding done.

June 2010

Standard 04.01. This document is up-issued to support Avaya Communication Server 1000 Release 7.0.

December 2009

Standard 03.03. This document is up-issued to support Communication Server 1000 Release 6.0. This document contains updates to the IP Phone 2007 LCD.

May 2009

Standard 03.02. This document is up-issued to support Communication Server 1000 Release 6.0.

April 2008

Standard 02.01. This document is issued to support Communication Server 1000 Release 5.5 for UNISlim 3.0.

May 2007

Standard 01.02. This document is issued to support Communication Server 1000 Release 5.0. This document

contains information previously contained in the following legacy document, now retired: IP Phone 2007 Call Center User Guide (NN10300-020). Graphics are also updated.

August 2005

Standard 2.00. This document is up-issued to support the Communication Server 1000 Release 4.5.

May 2005

Standard 1.00. This document is issued to support the IP Phone 2007 on Communication Server 1000 Release 4.0.

About the Avaya 2007 IP Deskphone

The Avaya 2007 IP Deskphone brings a premier multimedia experience to the IP Deskphone and offers color touch-screen that enables the presentation of a wide array of information and applications. It supports the services provided by Application Gateway 2000. The Avaya 2007 IP Deskphone display can present multimedia content to enhance your communications experience, including visual voicemail, broadcast alerts such as company news and emergency notifications, promotion of guest services within hospitality environments for revenue generation as well as other customized applications desired by the organization.

The Avaya 2007 IP Deskphone brings voice and data to the desktop by connecting directly to a Local Area Network (LAN) through an Ethernet connection.

The Avaya 2007 IP Deskphone provides all the functionality of the IP Phone 2004, using a graphical user interface (GUI). In addition, advanced text and graphic-based Web-centric applications are supported.

The Avaya 2007 IP Deskphone does not support the IP Deskphone Key Expansion Module (KEM).

Note: Not all features are available on all phones. Consult the system administrator to verify which features are available.

Basic features

The Avaya 2007 IP Deskphone supports the following features:

- large, color, touch panel display screen
- high quality speaker phone.
- 12 programmable feature keys: six programmable line (DN)/feature keys and six lines/features accessed by pressing the Shift key
- four context-sensitive soft keys

- volume control bar for adjusting ringer, speaker, handset, and headset volume
- five call-processing fixed keys:
 - Hold
 - Goodbye
 - Handsfree
 - Mute
 - Headset
- shared LAN access with a PC
- automatic network configuration
- hearing-aid compatibility
- Web-based applications support
- remote firmware download
- USB mouse and keyboard support or mouse

Note: Consult your system administrator to verify if your Avaya 2007 IP Deskphone is configured to support soft key functionality.

IP Deskphone controls

Figure 1 on page 10 shows the Avaya 2007 IP Deskphone.

Figure 1: Avaya 2007 IP Deskphone



Use the **Volume control** bar to adjust the volume of the ringer, handset, headset, speaker, and the Handsfree feature. Press the right side of the rocker bar to increase volume, the left side to decrease volume.



Use the **Goodbye** key to terminate an active call.



Press the **Hold** key to put an active call on hold. Tap the flashing line (DN) soft key to return to the caller on hold.



Use the **Navigation** key to scroll through menus and lists appearing on the LCD screen. The key rocks for up, down, left, and right movements.



Press the **Headset** key to answer a call using the headset or to switch a call from the handset or handsfree to the headset. The LED next to the headset button flashes when the headset is in use.



Press the **Handsfree** key to activate handsfree. The speaker LED indicator lights to indicate when handsfree is active.



Your **Mute** key functionality is enabled or disabled by your system administrator. Contact your system administrator to determine if your **Mute** key is enabled.

If your **Mute** key is enabled, press the **Mute** key to listen to the receiving party without transmitting your voice. Press the **Mute** key again to return to two-way conversation.

If your **Mute** key is not enabled, pressing the **Mute** key places the call on hold. Press the **Mute** key again to restore the active call or press the line key to restore the active call. You cannot retrieve this call from hold by pressing the Hold key.

Note: The Mute LED indicator, located on the **Mute** key, flashes to indicate that the microphone is muted.



When a message is waiting, or there is an incoming call, the red **Message Waiting/Incoming Call Indicator** LED at the top center of the IP Deskphone flashes. The flash cadence for each alert is different.

Note: You may also hear an audio Message Waiting Indicator (stutter or beeping dial tone) when you go off-hook.



Context-sensitive soft keys are located on either side of the navigation key. The LCD label above each key changes, based on the active feature. These keys are sometimes referred to as **soft keys**.

IP Deskphone Display


The Avaya 2007 IP Deskphone provides a large, color, touch panel display that supports color XML/HTML content through an external application server.

The Avaya 2007 IP Deskphone window-based user interface has two display areas:

- Application area
- Tools/Navigation area

Figure 2 shows an idle display.

Figure 2: Avaya 2007 IP Deskphone display



Note: The display can differ from the above example.

To extend the life of the LCD panel, the panel goes dark (“sleeps”) after a configured period of time. For information about configuring the time before the display sleeps, see the *Avaya 2007 IP Deskphone User Guide (NN43118-100)*.

Application area

The Application area provides:

- line and feature key status
- information items such as caller number, caller name, feature prompt strings, user-entered digits, date and time information (or call timer, if provisioned in the Telephone Options menu), and IP Deskphone information
- context-sensitive soft keys
- feature keys

Figure 3 shows the Application area and the feature area, the soft keys can show either text or icons.

Figure 3: Avaya 2007 IP Deskphone Detailed in Application area
















Table 1 shows the soft key text and icon equivalents. The text labels are displayed by default and are changed using the Tools menu.

Your Avaya 2007 IP Deskphone displays different icons and text labels depending on the version of your IP Deskphone and the installed firmware, as shown in Table 1.

Table 1: Feature key text and icon displays (Part 1 of 2)

Avaya 2007 IP Deskphone older version		Avaya 2007 IP Deskphone newer version	
Text display	Icon display	Text display	Icon display
Inbox		Inbox	

Table 1: Feature key text and icon displays (Part 2 of 2)


Avaya 2007 IP Deskphone older version		Avaya 2007 IP Deskphone newer version	
Text display	Icon display	Text display	Icon display
Directory		Directory	
Outbox		Outbox	
Quit		Quit	
Expand		Expand	
Services		Services	
Copy		Copy	

Tools/Navigation area

The Tools/Navigation area provides controls for navigating between features and selecting tools. This area is visible and functional at all times unless you tap the keyboard icon. The pop-up keyboard occupies this portion of the screen.

Figure 4 on page 16 shows the Tools/Navigation area.

Figure 4: Avaya 2007 IP Deskphone Tools/Navigation area



The Tools/Navigation area has five main elements presented as touchable soft keys. The icons on the soft keys are different depending on the installed IP Deskphone software.



Applications

Tap this icon to determine which external applications are registered (for example, My CallPilot), and launch them by tapping on the appropriate icon.



Telephone

Tap this icon to access the **Telephone** screen.



Primary Application

Tap this soft key to go to the primary external application, as configured by the administrator. The key displays the icon of the primary application.



Tools

Tap this icon to access the following tools used on the Avaya 2007 IP Deskphone. You can be prompted to enter the Administration password.

- Network Configuration
- Local Diagnostics
- Touch Panel Setup
- Display Settings
- USB Devices
- Preferences
- Lock Menu

Note: Network Configuration, Local Diagnostics, and TFTP Upgrade are for administrator use only.



Keyboard

Tap this icon to display a virtual keyboard (pop-up keyboard) for text entry.

The stylus or USB keyboard can be used to enter text in some of the applications. See [“Entering and editing text” on page 19](#) for further information.

Touch panel

You perform point-and-click operations on your Avaya 2007 IP Deskphone using the touch panel. The touch panel is used with the graphical user interface (GUI) to present soft keys directly on the display. You can activate all Line/DN soft keys and feature soft keys by using the touch panel.

For important information about cleaning your touch-panel, see [“Cleaning the phone Screen” on page 18](#).

Calibrate the touch panel

You calibrate the touch panel through the **Tools** menu, where you can fine-tune the touch panel. You are prompted to use the stylus to tap three targets. For more information, see the *Avaya 2007 IP Deskphone User Guide (NN43118-100)*.

Using the stylus

You operate the touch panel using a stylus or your finger. However, use of a stylus is recommended to avoid damage to the touch panel.

Cleaning the phone Screen

Hold the **Goodbye** key down and gently wipe the phone screen with a soft, dry cloth.



CAUTION

Do not use any liquids or powders on the phone.
Using anything other than a soft, dry cloth can contaminate phone components and cause premature failure.

Entering and editing text

You can enter and edit text on your Avaya 2007 IP Deskphone using the following methods:

- “Entering text using the phone dialpad” on page 19
- “Editing text using the soft keys” on page 20
- “Entering text using the pop-up keyboard” on page 20
- “Entering text using the USB keyboard” on page 21

The use of any of these methods for text entry depends on the application. [Table 2](#) shows the applications and input devices that can be used for text entry:

Table 2: Application Text Entry

For:	Use:
Call server related applications (for example, changing feature key labels, adding personal directory entries or for dialing)	Dialpad Pop-up or USB keyboard for numeric entries only
Graphical applications	Pop-up or USB keyboard
Tools menu	Pop-up or USB keyboard Dialpad for numeric and text entries

Entering text using the phone dialpad

You use the dialpad to enter text when using features such as programming an Autodial key.

For example, to enter the letter A, press the number **2** key once. To enter the letter C, press the number **2** key three times.

Note: No letters are associated with the number **1** or the number **0** key. Punctuation is associated with the number **1**.

When entering IP addresses with the dialpad, the address is entered as xxx**xxx**xxx**xxx, and the phone translates this to xxx.xxx.xxx.xxx.

Editing text using the soft keys

You use soft keys to access text when you work with such applications as Personal Directory, Redial List, and Callers List.

Table 3 describes the soft key editing functions on the Avaya 2007 IP Deskphone.

Table 3: Editing soft key description

Soft key	Description
Cancel	Stop the current action.
Choose	Select a symbol.
Clear	Clear the input field.
Case	Switch the next character to either uppercase or lowercase.
Delete	Backspace one character.
Done/Select/Enter	Depends on application.
More..	Access additional soft keys.

Entering text using the pop-up keyboard

A full uppercase and lowercase keyboard and a number pad are available to enter text. The user can type on the keyboard with the stylus. The pop-up keyboard can be used to enter text in the tools and graphical applications.

For number entry in phone applications (for example, when dialing), the keyboard can be used to enter digits (0 to 9), as well as asterisk (*) and pound (#). Other characters are ignored.

Entering text using the USB keyboard

The USB keyboard, when connected, can be used to enter text in the tools and graphical applications.

For number entry in phone applications (for example, when dialing), the keyboard can be used to enter digits (0 to 9), as well as * and #. Other characters are ignored.

When on a call, the function keys (f1, f2, f3, f4, f5, f6, f7, and f8) can be used to control the phone. [Table 4](#) shows the function keys and their associated action during phone calls.

Table 4: USB keyboard function keys during phone calls

Function key	Action
f1	Go to Handsfree mode
f2	Go to Headset mode
f3	Place the current call on Hold
f4	Mute the current call
f5	Volume Up
f6	Volume Down
f7	Copy
f8	Quit

Agent and Supervisor features

This section describes the following login features that are common to the Call Center Agent and Supervisor:


- Agent Login
- Login with Agent ID and Multiple Queue Assignments
- Agent Logout

Agent Login

Use the Agent Login to enter an Automated Call Distribution (ACD) queue. If an Agent ID is assigned, enter the four-digit code at the display screen prompts.



1. Lift the handset.



2. Tap the **InCalls** soft key.



3. If `Enter Agent ID` appears on the screen, use the dialpad to enter the ID.



4. Press the **#** key. The phone enters a Not Ready state.



5. To join the ACD queue, choose one of the following:



- Tap the **InCalls** soft key.
- Tap the **NotReady** soft key.



6. If you are using a headset and the Handset On-Hook Means Log out (HOML) setting is configured to **No** by the administrator, then perform the following:
 - a. Press the **Headset** key and replace the handset in the cradle to receive calls on the headset.
 - b. Tap the **Services** soft key. Change the On-hook default path to Headset Enabled.

Note: If the HOML setting is configured to **Yes**, replace the handset to log out of the queue.

Login with Agent ID and Multiple Queue Assignments

A Multiple Queue Assignment (MQA) login involves entering a four-digit Agent ID and up to five ACD Directory Numbers (DN), with the option of adding a Supervisor ID and up to five Priority values.

Choose one of the following login procedures:

- Agent ID and MQA login options
- Default login

Agent ID and MQA login options

To enter ACD queues, use an Agent ID login with one of the following MQA login options:

- No Supervisor ID, No Priority
- Supervisor ID, No Priority
- No Supervisor ID, with Priority
- Supervisor ID, with Priority

Note: The system prevents a supervisor from entering a Supervisor ID when the supervisor is logging in to accept ACD calls. This includes logins where agents must enter a Supervisor ID.

The login options require the following entries in sequential order:

1. a four-digit Agent ID
2. a Supervisor ID (if the queue requires one)
3. up to five ACD DNs and priority values (if priority values are being used) terminated by # #

To log in



1. Tap the **InCalls** soft key.

2. Choose one of the following four login options:



- For No Supervisor ID, No Priority, dial the Agent ID # ACD DN 1 # ACD DN 2 # ACD DN 3 # ACD DN 4 # ACD DN 5 # #.



- For Supervisor ID, No Priority, dial the Agent ID # Supervisor ID # ACD DN 1 # ACD DN 2 # ACD DN 3 # ACD DN 4 # ACD DN 5 # #.



- For No Supervisor ID, with Priority, dial the Agent ID # ACD DN 1 # Priority 1 # ACD DN 2 # Priority 2 # ACD DN 3 # Priority 3 # ACD DN 4 # Priority 4 # ACD DN 5 # Priority 5 # #.



- For Supervisor ID, with Priority, dial the Agent ID # Supervisor ID # ACD DN 1 # Priority 1 # ACD DN 2 # Priority # 2 ACD DN 3 # Priority 3 # ACD DN 4 # Priority 4 # ACD DN 5 # Priority 5 # #.


Note: To choose the default Priority value or Supervisor ID, enter **#**.




3. Choose one of the following:
 - Tap the **InCalls** soft key.
 - Tap the **NotReady** soft key to enter the ACD queue.

Default Login

When you always use the same phone, use the Default Login to log in only one time at the beginning of a shift. The Default Login uses the login of the previous shift to enter the same ACD queues and with the same Supervisor.



1. Lift the handset.
2. Tap the **InCalls** soft key.
3. When `Enter Agent ID` appears on the screen, use the dialpad to enter the ID.
4. Choose one of the following:
 - If the queue requires a Supervisor ID, press the **#** key three times.
 - If the queue does not require a Supervisor ID, press the **#** key two times.




- To join the ACD queue, choose one of the following:
 - Tap the **InCalls** soft key.
 - Tap the **NotReady** soft key.

Agent Logout

Log out of the system completely or temporarily (NotReady state).

To log out



Choose one of the following:

- To log out completely, press the **MakeSetBusy** soft key.
- To log out temporarily, press the **NotReady** soft key.

Note: While on an ACD call, tapping the **MakeSetBusy** soft key results in automatic logout when the call finishes.

Agent features


The following sections describe features available to Agents:

- Answer ACD calls
- Activity code
- Call Forcing
- Emergency
- Not Ready
- Answer or Place Non-ACD calls
- Contact the Supervisor

Answer ACD calls

Use the **InCalls** key to answer the next queued ACD call on the primary DN. The **InCalls** key is located in the lower right-hand corner of the programmable line/feature keys.

To answer the call



When the **InCalls** soft key flashes, tap the **InCalls** soft key.

To terminate the call



Choose one of the following:

- Press the **Goodbye** key.
- Tap the **Incalls** soft key.
- Tap the individual DN line soft key (to be removed from the queue).
- Tap the **NotReady** soft key (to be removed from the queue, but to remain logged in as an agent position) or wait for the caller to terminate the call.

Use Force Call

Use the Force Call feature to automatically connect to an incoming ACD call. A time interval is set by the system administrator between each incoming call.

When calls come in, a short tone indicates the new call. The InCall soft key changes color, and the ACD call automatically goes to the agent position. Pressing the **Incalls** key while call forcing (Auto Answer) is active disconnects an active ACD call.

To enable call forcing for headset users

1. Log in.
2. Replace the handset.




 Services

3. Press the **Services** soft key. Set the On-hook default path to Headset Enabled.

Use Activity code

You use Activity codes to record the types of activities performed.

To record activities


 Activity


 Activity

1. When the Activity soft key is flashing, tap the **Activity** soft key.
2. Use the dialpad to enter the Activity code.
3. Tap the **Activity** soft key.

If performing multiple tasks, repeat these steps.

Note: If configured, Activity codes can be entered while in the NotReady state.

Use Emergency


Use the Emergency feature to contact the supervisor immediately in an emergency situation.



1. During an active call, tap the **Emergency** soft key.

Note: The Emergency soft key color changes and remains altered as long as the feature is active.

When the supervisor answers, a three-way call commences.



2. Tap the **Emergency** soft key again to transfer the caller to the supervisor and terminate access to the caller and supervisor.


Use Not Ready

Use the Not Ready feature to take the phone out of the call queue while completing post-call work.



1. Tap the **NotReady** soft key to temporarily log out of the system.

Note: The **NotReady** soft key color changes and remains altered as long as the feature is active.




2. To return to the queue, choose one of the following:
 - Tap the **InCalls** soft key
 - Tap the **NotReady** soft key.

Place or answer non-ACD calls

Use this feature to place or answer calls on an individual line.


To place a call



1. Tap the individual DN soft key.
2. Use the dialpad to dial the phone number.

Note: The DN soft key color changes and remains altered as long as the call is active.

To answer a call



When the soft key for the individual DN soft key flashes, tap the DN soft key.

Note: The DN soft key color changes and remains altered as long as the call is active.

Contact the supervisor

Use the Supervisor feature to talk to the supervisor in the following ways:

- answer a call from the supervisor
- answer a call from the supervisor while on another call
- place a call to the supervisor
- conference in the supervisor while on another call
- transfer a call to the supervisor

To answer a call from the supervisor



When the **Supervisor** soft key flashes, tap the **Supervisor** soft key.

Note: The soft key color changes and remains altered as long as the call is active.

To answer a call from the supervisor while on another call



1. The **Supervisor** soft key flashes and a buzzer sounds.




2. Press the **Hold** key to put the current call on hold.



3. Tap the **Supervisor** soft key.

Tap the flashing line (DN) soft key to return to the caller on hold.

To place a call to the supervisor



Tap the **Supervisor** soft key.

Note: Calls are automatically put on hold when the Supervisor soft key is used.

To return to the ACD call



Tap the **InCalls** soft key.

To conference in the supervisor during a call in progress




1. Tap the **Supervisor** soft key to talk privately with the supervisor.



2. Tap the **Supervisor** soft key again for a conference call.

To transfer a call to the supervisor during a call in progress



1. Tap the **Supervisor** key.



2. When the supervisor answers, tap the **Supervisor** key again.



3. Press the **Goodbye** key to terminate access to the call.

Using Record On Demand key

If this feature is enabled, you can use the Record on Demand (ROD) feature key to record your telephone conversation.

Press the ROD key to start or stop the call recording. This key is associated with the active user ID and is displayed only if a call is active. The ROD key blinks while it is connecting to the call recording application, and is lit when the call is recording.

The ROD key is displayed in the following scenarios:

- Normal operation - Press the ROD key during an active call to record the call.
- Call Recording (CR) application in ROD Mode - Press the ROD key during an active call to record the call
- Bulk Recording - For an active call or unregistered DN/Position ID, call recording is initiated even though the ROD key is not pressed.

1. Press the **ROD** key during an active call.
2. To stop the call recording, press the **ROD** key again.

Using SAVE key

Use the **SAVE** feature key to save the recording of an active call. This key is associated with the active user ID and is operational only if a call is active.

The **SAVE** key is displayed in the following scenarios:

- Normal operations - If the **SAVE** key is pressed during an active call, the call is saved.

- CR application in Bulk Record + Save everything mode - Recorded conversation is saved at the end of the call. If the **SAVE** key is pressed, then the call is not saved.
- CR application in Bulk Record + Delete everything mode - Recorded conversation is deleted at the end of the call. If the **SAVE** key is pressed, then the call is saved.

The **SAVE** key lamp status depends on the status of the call recording. If the call is to be saved, then the lamp is lit.

1. Press the **ROD** key during an active call.
2. To stop the call recording, press the **ROD** key again.
3. Press the **SAVE** key to save the conversation.

Using voice mail soft keys

Note: This feature is not available on all telephones. Contact your system administrator to determine if this feature is available on your telephone.

When this feature is enabled, then when you access your voice mail, either by tapping the Messages/Inbox key, or by dialing your voice mail access number, voice mail soft keys are displayed that let you perform various actions for your messages.

The following soft keys are displayed:

Play	Delete	Call	More...
Stop	Conf	Reply	More...
Comp	Forwrd	Bye	More...

Soft key	Action
Play	Play the voice mail message.
Delete	Delete the voice mail message.
Call	Call the telephone number that left the voice mail message.
More...	Display the next layer of soft keys.
Stop	Stop playing the voice mail message.
Conf	Conference in another party to listen to the voice mail message.
Reply	Reply to the voice mail message.
More...	Display the next layer of soft keys.
Comp	Compose a voice mail message.
Forwrd	Forward the voice mail message to another telephone number.
Bye	Disconnect from the voice mail system.
More...	Cycle back to the first layer of soft keys.

Voice mail soft keys are displayed:

- when you press the Messages/Inbox key (internal and external)
- when you dial the voice mail access number manually (internal only)

Supervisor features

The following sections describe features available to the Supervisor:

- Answer Agent
- Agent key
- Answer Emergency
- Call Agent
- Interflow
- Night Service
- Observe
- Display Agent Status
- Display Queue

Use Answer Agent

Use the Answer Agent feature to receive calls from agents in a non-emergency situation.



1. When the Answer Agent soft key flashes, tap the **Answer Agent** soft key.

Note 1: The Agent ID of the contacting individual displays on the phone.

Note 2: The soft key color changes and remains altered as long as the call is active. The status changes to NotReady.



2. Press the **Goodbye** key to end the call.

Use Agent key

Use the Agent feature to connect, observe, or monitor the status of each agent position. Each **Agent** key links to a particular agent position, and can be used with the **Call Agent** or **Observe Agent** keys.


Table 5 lists the four states of the LCD indicator.

Table 5: Agent status

LCD	Description
Off	Agent is not logged in.
On	Agent is logged in but either NotReady or on a call.
Slow Flashing	Agent is waiting for an ACD call.
Fast Flashing	Agent is on a non-ACD call.

Use Answer Emergency

Use the Answer Emergency feature to receive calls from agents in an emergency situation.



1. When the **Answer Emergency** soft key flashes, tap the **Answer Emergency** soft key.

Note 1: The Agent ID of the contacting individual displays on the phone.

Note 2: The soft key color changes and remains altered as long as the call is active. The status changes to NotReady.



2. Press the **Goodbye** key to end the call.

Use Call Agent

Use the Call Agent feature to contact an Agent.



1. Tap the **Call Agent** soft key.



2. Choose one of the following:
 - Tap a selected **Agent** soft key.
 - Dial the agent's Position ID.



3. Press the **Goodbye** key to end the call.

Use Interflow

Use the Interflow feature to redirect calls when the backlog or wait time exceeds a predefined threshold.



1. Tap the **Interflow** soft key.

Note: The **Interflow** soft key color changes and remains altered while the feature is active.



2. Tap the **Interflow** soft key again to deactivate the feature and resume normal call flow.

Use Night Service

Use the Night Service feature to define how calls are handled outside of business hours.

To activate Night Service



1. Tap the **Night Service** soft key.

2. Press the **6** key (6 = N for Night) to go into Night Service.

The **Night Service** soft key color changes and remains altered. All calls in queue and new calls receive night service.

To transition to Night Service



1. Tap the **Night Service** soft key.

2. Press the **8** key (8 = T for Transition) to activate Transition mode.

The **Night Service** soft key color changes and remains altered. All calls in queue remain in queue and new calls receive Night Service.

To deactivate Night Service



1. Tap the **Night Service** soft key.




2. Press the **3** key (3 = D for Day) to resume Day mode.

The **Night Service** soft key color changes and remains altered. New calls enter the queue.

Observe


Use the Observe feature to monitor an agent in a call.




1. Tap the **Observe** soft key.



2. Choose one of the following:
 - Tap a selected **Agent** soft key.
 - Dial the agent's Position ID.



3. Tap the **Call Agent** soft key to talk to the agent being monitored.



4. Tap the **Observe** soft key to terminate the observation.

Display Queue

Use the Display Queue feature to access the status of calls in an ACD queue. The information displayed includes the following:

- number of calls waiting in the queue
- number of agent positions occupied for the queue

- length of time the oldest call has waited in the queue
- number of calls that have overflowed into the queue

To display information on the ACD queue

DisplayQueue

Tap the **Display Queue** soft key.

Information on the current ACD queue appears on the display.

Figure 5: Current status of ACD queue



Display Agent status

Use the Display Agent feature to view a summary of the current status for all agents who have an agent Position ID key assigned on the supervisor's phone.

DisplayAgt

Tap the **Display Agent** soft key. The summary information displays for twelve seconds or until another feature key is pressed.

Agent positions in the Not Ready state are counted as busy on either ACD calls or non-ACD calls, as specified by the system administrator.

Figure 6: Current status of agents



The **Display Queue** soft key gives a visual indication of the number of calls in the ACD queue. [Table 6](#) lists the four states for this soft key.

Table 6: Display Queue soft key states

Soft key display	Queue status	Description
Off	Light	There are few or no calls waiting.
On	Normal	An acceptable number of calls are waiting.
Slow Flashing	Busy	Calls are backing up in the queue. Calls overflowing to this queue are not accepted.
Fast Flashing	Overloaded	Too many calls in this queue. New calls are overflowed to another queue.

Terms you should know

Attendant

A telephone operator in your organization.

AutoDial

A telephone number programmed on the **AutoDial** soft key for one-touch dialing.

Avaya Communication Server 1000

An office communication system.

Copy key

A soft key used to copy entries to your Personal Directory from other lists, such as the Callers List, Redial List, Corporate Directory, etc.

Date/Time display

The current date and time when the telephone is in an idle state.

Directory soft key

Enables access to Corporate Directory, Personal Directory, Redial List, and Callers List.

Directory Number (DN)

A number consisting of one to seven digits for a telephone. Also known as an *extension number*.

Expand to PC

A soft key on your telephone used to access external server applications.

Fastbusy

A signal given when all outgoing lines are busy.

Feature display

An area that shows status information about the feature in use. It also displays the name and status of the active session.

Fixed key

Any of the hard-labeled keys on your telephone.

Goodbye key

A fixed key used to end an active call.

Handsfree

A method of conversing with the party on the other end of the line without lifting your handset.

Headset key

A fixed key used to answer a call using the headset.

Hold key

A fixed key used to place an active call on hold.

Information display

Any display of call activity, lists, prompts, and status of calls.

Information line

A 1-line by 24-character area that displays date and time or application information.

Interrupted dial tone

A broken or pulsed dial tone you hear when you access some features on your telephone.

Message (Inbox)

A soft key on your telephone that connects to your voice messaging system when the key is tapped.

Message Waiting indicator/Incoming Call indicator

An LCD or an LED that indicates the status of a feature by the flash, wink, steady on, or off.

Meridian 1

An office communication system.

More..

An option allowing access to the multiple layers of the soft keys.

Mute key

A fixed key used to listen to a caller without transmitting.

Navigation key

Contains the Up/Down and Left/Right keys used to scroll through menus and lists appearing on the LCD display screen.

Off-hook

Any line selected to make a call or receive an incoming call. The term *off-hook* is applied whether (a) the end user lifts up the handset, (b) the end user presses a line key, (c) the call is automatically answered at the set, or (d) a line is automatically selected for an outgoing call.

Outbox/Shift key

A soft key used to switch between two feature key sets to provide access to an additional six lines/features.

Primary Directory Number

The main extension number on your telephone.

Programmable line (DN)/feature soft keys (self-labeled)

The six soft keys located in the upper area of the display.

Quit key

A soft key on your telephone that is used to exit applications.

Ringback/ring tone

A sound indicating that a call you have made is ringing at its destination.

Services key

A soft key used to access options, such as Telephone Options, Password Admin, Display Network Diagnostics Utilities, Virtual Office Login, Virtual Office Logout, Test Local Mode, and Resume Normal Mode.

Soft keys

A set of keys programmed by your system administrator. These four keys, located in the middle of the display area, have four programmable layers that are accessed through the **More..** soft key. These keys are also used to configure parameters in the **Telephone Options** menu.

Speaker key

A fixed key used to activate Handsfree.

Special dial tone

The three consecutive tones followed by dial tone that you hear when accessing telephone features.

Status messages

A message displayed to inform the user of important information. A right arrow appears if more than one status message is present. Examples of status messages include: Message Waiting, All Lines Forwarded to: 6453, Do Not Disturb On, Ring Again Active, Ringer is OFF, and Line x Unavailable.

System or Switch

Your office communication system.

Switchhook

A button that the handset depresses, disconnecting your call when you replace the handset. When lifted, the handset releases the switchhook, and you either answer an incoming call or you receive a dial tone to make a call.

User interface

Screen displays that interact with the end user as a result of an action or event.

Volume control bar

A rocker bar you press to increase or decrease the volume of the ringer, handset, headset, speaker, and the Handsfree feature.

Regulatory and safety information

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/ TV technician for help.

Note: The user should not make changes or modifications not expressly approved by Avaya. Any such changes could void the user's authority to operate the equipment.

This Class B digital apparatus complies with Canadian ICES-003. Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

Warnings:

- This is a Class B product. In a domestic environment this product can cause radio interference in which case the user must take adequate measures.
- Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

この装置は、情報処理装置等電波障害自主規制協議会（VCCI）の基準に基づくクラスB情報技術装置です。この装置は、家庭環境で使用することを目的としていますが、この装置がラジオやテレビジョン受信機に近接して使用されると、受信障害を引き起こすことがあります。

取扱説明書に従って正しい取り扱いをして下さい。

Table 7 lists EMC compliance for various jurisdictions.

Table 7: EMC Compliance

Jurisdiction	Standard	Description
United States	FCC CFR 47 Part 15	Class B Emissions: FCC Rules for Radio Frequency Devices
Canada	ICES-003	Class B Emissions: Interference-Causing Equipment Standard: Digital Apparatus
Australia/New Zealand	AS/NZS 3548 CISPR 22	Class B Emissions: Information technology equipment - Radio disturbance
European Community	EN 55022	Class B Emissions: Information technology equipment - Radio disturbance
	EN 55024	Information technology equipment - Immunity characteristics Limits and methods of measurement
	EN 61000-3-2	Limits for harmonic current emissions (equipment input current \leq 16 A per phase)
	EN 61000-3-3	Limitation of voltage fluctuations and flicker in low-voltage supply systems for equipment with rated current \leq 16 A
Japan	VCCI	Regulations for voluntary control measures.


Table 8: Safety

Jurisdiction	Standard	Description
United States	UL 60950-1	Safety of Information Technology Equipment
Canada	CSA 60950-1-03	Safety of Information Technology Equipment
European Community	EN 60950-1	ITE equipment - Safety - Part 1: General requirements
Australia/New Zealand	AS/NZS 60950.1:2003	Safety of Information Technology Equipment

Other Safety Approvals: IEC 60950-1: ITE equipment - Safety - Part 1: General requirements

Other

US/Canada: Hearing Aid Compatibility (HAC) as per FCC Part 68

This equipment complies with the CE Marking requirements. 

Australia: AS/ACIF S004: Voice Frequency Performance Requirements for Customer Equipment

EU Countries: This device complies with the essential requirements and other relevant provisions of Directive 1999/5/EC. A copy of the Declaration may be obtained from <http://support.avaya.com/css/appmanager/public/support>

DenAn regulatory notice for Japan

Warning

Please be careful of the following while installing the equipment:

- Please only use the Connecting cables, power cord, AC adaptors shipped with the equipment or specified by Avaya to be used with the equipment. If you use any other equipment, it may cause “failures, malfunctioning or fire”.
- Power cords shipped with this equipment must not be used with any other equipment. In case the above guidelines are not followed, it may lead to death or severe injury

警告

本製品を安全にご使用頂くため、以下のことにご注意ください。

- 接続ケーブル、電源コード、ACアダプタなどの部品は、必ず製品に同梱されております添付品または指定品をご使用ください。添付品・指定品以外の部品をご使用になると故障や動作不良、火災の原因となることがあります。
- 同梱されております付属の電源コードを他の機器には使用しないでください。上記注意事項を守らないと、死亡や大怪我など人身事故の原因となることがあります。

Index

A

About the Avaya 2007 IP Desk-phone 8
Activity code 30
Agent and MQA login options 24
Agent and Supervisor features 22
Agent features 28
Agent key 39
Agent login 22
Agent logout 27
Answer ACD calls 28
Answer Agent 38
Answer Emergency 39
Attendant 46
AutoDial 46
Avaya Communication Server 1000 46

B

Basic features 8

C

Calibrate the touch panel 18
Call Agent 40
Cleaning the telephone screen 18
Contact your supervisor 33
Copy key 46

D

Date/Time display 46
Default login 26

Directory key 46
Directory Number (DN) 46
Display Agent status 44
Display Queue 42

E

Emergency 31
Expand to PC key 46

F

Fastbusy signal 47
Feature display 47
Fixed key 47
Force Call 29

G

Goodbye key 10, 47

H

Handsfree 47
Headset key 11, 47
Hold key 10, 47

I

Indicator status 48
Information display 47
Information line 47
Interflow 40
Interrupted dial tone 47

L

Local Area Network 8

Login with Agent ID and MQA 23

M

Meridian 1 48, 50

Message (Inbox) 48

Message waiting indicator 48

More key 48

Mute key 11, 48

N

Navigation keys 10, 48

Night Service 41

Not Ready 31

O

Observe 42

Off-hook 48

Outbox/Shift key 48

P

Paging tone 48

Place or answer non-ACD calls 32

Primary Directory Number 48

Programmable line (DN)/feature keys (self-labeled) 49

Q

Quit key 49

R

Regulatory and safety information 52

Ringback/ring tone 49

S

Services key 49

Soft keys (self-labeled) 49

Speaker key 11, 49

Special dial tone 49

Status messages 50

Supervisor features 35

Switchhook 50

System or Switch 50

T

Touch panel 17

 cleaning 18

U

User interface 50

V

Volume control bar 10, 50